

Assembly Instruction									
Cromax® Pro Tinting Tool UPD 2014									
zum Einsortieren zwischen/ to sort in between/ pour placer entre									
Swatch	CHIP before			Mixing tint	Mixing ratio	Mixing tint	CHIP behind		
#2	WB05	1:1	WB01	WB9908	100%		WB9908	1:1	WB05
	WB9908	100%		WB9908	1:1	WB05	WB9908	1:1	WB06
	WB9908	1:1	WB05	WB9908	1:1	WB06			
#3	WB1025	9:1	WB1031	WB1097	100%		WB1097	1:1	WB24
	WB1097	100%		WB1097	1:1	WB24	WB1098	100%	
	WB1097	1:1	WB24	WB1098	100%		WB1098	1:1	WB24
	WB1098	100%		WB1098	1:1	WB24	WB1779	100%	
	WB1098	1:1	WB24	WB1779	100%		WB1779	1:1	WB06
	WB1779	100%		WB1779	1:1	WB06			