

Assembly Instruction								
Cromax® Pro Tinting Tool UPD 2015								
zum Einsortieren zwischen/ to sort in between/ pour placer entre								
Swatch	CHIP before			Mixing tint	Mixing ratio	Mixing tint	CHIP behind	
#1	WB53	1:3	WB1033	WB54	MASSTONE		WB54	1:5 WB01
	WB54	MASSTONE		WB54	1:5	WB01	WB54	1:1 WB01
	WB54	1:5	WB01	WB54	1:1	WB01	WB54	1:3 WB1033
	WB54	1:1	WB01	WB54	1:3	WB1033	WB60	MASSTONE
#2				WB61	MASSTONE		WB61	1:5 WB01
	WB61	MASSTONE		WB61	1:5	WB01	WB61	1:1 WB01
	WB61	1:5	WB01	WB61	1:1	WB01	WB61	1:3 WB1033
	WB61	1:1	WB01	WB61	1:3	WB1033	WB62	MASSTONE